

EZ Up Tent Tie Down

1. Secure a dog tie-out stake (auger-type that you screw into the ground) underneath the center of your tent. Slip a hammer handle through the center loop if you need force to turn the tie-out into the ground. Then, of course, remove the hammer



2. Attach one end of a dog leash to the center support of your E-Z up. Secure the other end to the loop at the end of the tie-out on the ground. Pull the leash tight to take the slack out



This method only works with E-Z Up styles of tents which have a center support. It works whether the tent is secured up or down. You can see Tom Thompson if you have a different style of tent and want to figure out a way to secure it in high winds